

# Remote Control Module Instruction




1. Overall Dimensions




2. Front Impression Drawing

## 3. Function Description Drawing



- 1 Power Switch ON&OFF
- 2 RJ45 Port (Remote Control)
- 3 RS232 Port (Optional)

## 4. Connection Diagram



#### 5.LCD Display

#### SYSTEM OVERVIEW

Input AC: 000 V Output AC: 000 V Batt DC: 0000 V Output Freq: 0000Hz Output Load: 000% Work mode: Online

Alarm: NO

Fault: NO



Input Ac: Real AC Input Line Voltage

Batt Dc: Real Battery Voltage Or Charging Voltage

Output Load: Real AC Load Percentage

Alarm: Yes Or No (Ref Manual)

Fault: Yes Or No (Ref Manual)

Output Ac: Real AC Output Voltage

Output Freq: 50Hz Or 60Hz

Work Mode: Online Or Inverter

